



REPLACE 140 SERIES HEADLINING

Preparation

Headlining should be unpacked and spread out at least a week before mounting shall take place. It shall be in a roomtemperated place. To many other cars & brands in (i.e Ford Mustang) with "hanging" headlining it is recommended to pe placed in the sun to get rit of wrinkles and other matrial "prints" which have occured during storing. This will also help material to become more "soft" or stretch when mounting. This preparation is applicable for almost all vinyl headlinings (plastic).

Monting should be done in a place temperated to simplyfy process. For help it could be good to have an hot-airgun or car heating fan. Just beware of the overheating danger. Another thing to think about when replacing headling and make it eaisier is: When screens and windows are demonted (and car is repainted). All seats are demounted.



Tools?

Not necessary, but som sort of heat source as above mentioned. Maybe some kind of spatula , ATTENTION -NO SHARP EDGES, what so ever. But it can come hande to help getting the plastic edge into the roofrail.