

# Headrest

## *Mounting instructions*

For fitting on core/s: part #680126, (alternative part #686367 & 1210882)

**120 – 130 -- 220 – 140 – 160 – P1800**

- Check the product/s
- Read instructions below once before starting.
- Tools: Hot air gun, a piece of metal (rounded W/O sharp edges)

**New covers 20090102 (size extended & new materials with more stretch):**

### **START**

- Attach elastic sock over headrest, trim away surplus roughly 5cm from bottom of headrest.



\\VP-

SRV01\Bibliotek\Kalkyler\_Dokument\Inredning\AZ\130\Headrestmountinginstructions.doc

- Put cover over core in one end. Make sure of front side. The “she” connector should be at front side.
- Front side = soft side



\\VP-

SRV01\Bibliotek\Kalkyler\_Dokument\Inredning\AZ\130\Headrestmountinginstructions.doc

- Turn other short side of cover inside out like picture below, not to much. Use end at piping to pull. Toggle from right to left a short bit at the time.



\\VP-

SRV01\Bibliotek\Kalkyler\_Dokument\Inredning\AZ\130\Headrestmountinginstructions.doc

- When corner of headrest core is reached, turn cover back again. Now cover should be wrapped around core. Massage cover to be centred over core. Make sure that piping flags inside are folded towards middle section of vinyl parts. (This makes a better look).



- Now use the suggested tool to join connectors. Push at the “she” connector onto the “male”. The first ½ - 1 inch could be join with hands.
- Don't mount the plastic holecovers yet.



\\VP-

SRV01\Bibliotek\Kalkyler\_Dokument\Inredning\AZ\130\Headrestmountinginstructions.doc

- Now massage cover to be nicely fitted and placed over core so when plastic covers are pushed down in place, will cover the vinyl.



\\VP-

SRV01\Bibliotek\Kalkyler\_Dokument\Inredning\AZ\130\Headrestmountinginstructions.doc

**Older materials (stiffer):**

- 
- Warm up the cover with air gun (se picture), be careful. Start with lower heat and increase if necessary.
- Let the vinyl be soft before mounting on core. Locate front and rear face.

Put core in one end and pull over to the other end while cover still is soft. Refer to above instruction for newer materials.

Be gentle, heat some more while pulling it over core if necessary.

