

TRIM INSTRUCTIONS FOR 122 RUBBER MATS

Since the mat manufacturer supplies these mats without removing excess material, we include this instruction for you to use as a guide when trimming to fit your 122.

Front rubber mat (Black: 670698R / Grey: 670867)

Trim waste material surrounding the mat by following the thin line that runs around the entire mat about an inch into it. You will probably need to remove a bit more material, but do that with the mat in position in the vehicle.

If your car has a manual gearbox, you should cut a hole where the “V” emblem is located. For models 1965-70 you will also need to cut an oval hole to hook up the air duct from the heater. Models pre 1964 don't have this connection.

There are also markings for cuts you need to make to fit the mat under the front seats. Cut a hole where the circle marking is, and just follow the thin line from there.

Rear rubber mat (Black: 670699 / Grey: 670868)

Put the mat in position in the car, and trim the mat to fit. Note that 4 door cars as well as wagons are different from the 2 door model. This is why you should trim this mat in its coming environment.

Trunk mat (Black: 660677)

Put it in position in the trunk, and trim it to fit.